

## **Type 8741, 8742, 8746** **MFC / MFM**

Description to the display of the device status  
for the different software versions.

Beschreibung zur Anzeige des Gerätezustands  
für die unterschiedlichen Software-Versionen.

Supplement to the Operating Instructions

Ergänzung zur Bedienungsanleitung

We reserve the right to make technical changes without notice.  
Technische Änderungen vorbehalten.  
Sous réserve de modifications techniques.

© 2016 Bürkert Werke GmbH


Supplement to the Operating Instructions 1605/01\_EU-ML\_00810500 / Original DE

## Supplement to Operating Instructions







This instructions describes the change of the color assignment of the device status LED.

For following software versions:

- up to and including version A.07  
The color assignment based partly on Namur NE 107.
- version A.08 and higher.  
The color assignment is compliant with Namur NE 107.

 The MFM/MFC has an LED to display the device status, the color and status change accordingly to the device status. If more than one device status exists simultaneously, the device status with the highest priority is displayed.

### Color code overview

| Color   | Color code Hex/Dec |          |          |
|---|--------------------|----------|----------|
|   | Lit                | Blinking | Flashing |
|  White  | 0/0                | 10/16    | 20/32    |
|  Green  | 1/1                | 11/17    | 21/33    |
|  Blue   | 2/2                | 12/18    | 22/34    |
|  Yellow | 3/3                | 13/19    | 23/35    |
|  Orange | 4/4                | 14/20    | 24/36    |
|  Red    | 5/5                | 15/21    | 25/37    |

Tab. 1: Color code Hex/Dec

## Display of the device status – up to and including software version A.07

The color assignment based partly on Namur NE 107.

| LED        | Color code Hex/Dec |          |                     | Description                                      | Description of device status   |  | What to do?          |
|------------|--------------------|----------|---------------------|--|--|--|----------------------|
|            | Lit                | Blinking | Flashing            |  |  |  |                      |
| No color   | –                  | –        | –                   | –  | The device is not energized.   |  | Energize the device. |
| All colors | 0...9/0...9        |          |                     | Device is in AUTO-MATIC operating state          | The device is using the standard set-point value for control.  |  | –                    |
|            |                    |          | 20...29/<br>32...41 | Identification: Device connected to the network. | Identifies a device on the bÜS network. „Flashing“ status is started when the device is selected in the „Bürkert Communicator“ software. | After 10 seconds, the device automatically returns to the previous status („lit“ or „blinking“). |                      |
| White      | 0/0                | 10/16    | 20/32               | Normal operation                                 | Device is in AUTOMATIC operating state.  |  | –                    |
|            |                    |          |                     | Normal operation                                 | bÜS  | Control loop disabled, direct specification of the variable to the valve.                        | –                    |
|            |                    |          |                     |  |  | Setpoint source is manual set-point value specification.   | –                    |
|            |                    |          |                     |  | CANopen  | The device is in the “Pre-operational” state.  | –                    |
| Green      | 1/1                | –        | 21/33               | Diagnostics active                               | AUTOTUNE active  |  | –                    |
|            |                    |          |                     |  | SYSTEM ANALYSIS function active  |  | –                    |

| LED    | Color code Hex/Dec |          |          | Description          | Description of device status  | What to do?  |
|--------|--------------------|----------|----------|----------------------|---|--|
|        | Lit                | Blinking | Flashing |                      |   |  |
| Blue   | 2/2                | –        | 22/34    | Maintenance required | Memory error.<br>Error detected in the calibration curve.   | Maintenance is needed –<br>Contact the manufacturer.   |
| Yellow | 3/3                | –        | 23/35    | Out of specification | <i>AUTOTUNE</i> defective and aborted.  | Restart <i>AUTOTUNE</i> .  |
| Orange | 4/4                |          | 24/36    | Warning              | Device is in AUTOMATIC operating state.   | –  |
|        |                    |          |          |                      | Medium or device temperature out of specification, potential destruction of the sensor or device.                       | Operate the device within the specifications.  |
|        |                    |          |          |                      | The control variable for the proportional valve has been (almost) 100% reached. The set-point value cannot be attained. | Increase the operating pressure (observe the maximum permissible supply pressure).<br>Check the pressure drop in the pipe and reduce it if necessary.<br>Check the dimensions of the installation.<br>Check the filters installed in the pipe and clean them if necessary. |

| LED    | Color code Hex/Dec |          |          | Description | Description of device status  | What to do?  |
|--------|--------------------|----------|----------|-------------|---|--|
|        | Lit                | Blinking | Flashing |             |   |  |
| Orange |                    | 14/20    |          | Warning     | Calibration activated   | –  |
|        |                    |          |          |             | The device is in MANUAL operating state.<br>The control variable for the proportional valve has been (almost) 100% reached. The set-point value cannot be attained. | Increase the operating pressure (observe the maximum permissible supply pressure).<br>Check the pressure drop in the pipe and reduce it if necessary.<br>Check the dimensions of the installation.<br>Check the filters installed in the pipe and clean them if necessary. |
|        |                    |          |          |             | Search for büS participants is active. Mode will exit after a few seconds.  | –  |
| Red    | 5/5                | –        | 25/37    | Error       | Sensor defect.  | Maintenance is needed –<br>Contact the manufacturer.   |
|        |                    |          |          |             | Memory defect.  |  |
|        |                    |          |          |             | Device defect.  |  |
|        |                    |          |          |             | Device cannot find the assigned büS participant.  | Review the allocation of the büS participant in the affected device.<br>Review the assigned büS participant and the their büS participant allocation.  |
|        |                    |          |          |             | Bus error (e.g. short circuit).   | Check the wiring.  |

Tab. 2: LED display of the device status and measures – up to and including software version A.07

## Display of the device status – software version A.08 and higher

The color assignment is compliant with Namur NE 107.

| LED<br>compliant with<br>NAMUR NE 107 | Color code Hex/Dec |                     | Description<br>according<br>NAMUR NE 107 | Description of device status                                  | What to do?  |
|---------------------------------------|--------------------|---------------------|--|---|--|
|                                       | Lit                | Flashing            |  |   |  |
| No color                              | –                  | –                   | –  | The device is not energized.                                  | Energize the device.   |
| All colors                            |                    | 20...29/<br>32...41 | –  | Device is selected using the „Bürkert Communicator“ software. | –  |
| Green                                 | 1/1                | 21/33               | Diagnostics<br>active                    | The device is supplied with<br>power.                         | The device is in <b>AUTOMATIC</b> operating<br>state or <b>STORED SETPOINT</b> . |
| Blue                                  | 2/2                | 22/34               | Maintenance<br>required                  | Memory error.<br>Error detected in the calibration<br>curve.  | Maintenance is needed – Contact the<br>manufacturer.                             |

| LED<br>compliant with<br>NAMUR NE 107 | Color code Hex/Dec |          | Description<br>according<br>NAMUR NE 107 | Description of device status  | What to do?  |
|---------------------------------------|--------------------|----------|--|---|--|
|                                       | Lit                | Flashing |  |   |  |
| Yellow                                | 3/3                | 23/35    | Out of specification                     | Medium temperature or device temperature or supply voltage out of specification, potential destruction of the sensor or device. | Operate the device within the specifications.  |
|                                       |                    |          |  | The control variable for the proportional valve has been (almost) 100% reached. The set-point value cannot be attained.         | Increase the operating pressure (observe the maximum permissible supply pressure).<br>Check the pressure drop in the pipe and reduce it if necessary.<br>Check the dimensions of the installation.<br>Check the filters installed in the pipe and clean them if necessary. |
|                                       |                    |          |  | Another fieldbus participant uses the same node ID.   | Assign a different node ID.  |



| LED<br>compliant with<br>NAMUR NE 107 | Color code Hex/Dec |          | Description<br>according<br>NAMUR NE 107 | Description of device status   | What to do?                       |
|---------------------------------------|--------------------|----------|--|--|-----------------------------------|
|                                       | Lit                | Flashing |  |  |                                   |
| Orange                                | 4/4                | 24/36    | Check function                           | <i>AUTOTUNE</i> active   | –                                 |
|                                       |                    |          |  | Calibration active   | –                                 |
|                                       |                    |          |  | Control loop disabled, direct specification of the variable to the valve.            | –                                 |
|                                       |                    |          |  | Setpoint source is <i>MANUAL SETPOINT</i> or <i>OPEN-LOOP-CONTROL</i> specification. | –                                 |
|                                       |                    |          |  | <i>SYSTEM ANALYSIS</i> function active   | –                                 |
|                                       |                    |          |  | büS mode only: Device searches for allocated participant.                            | –                                 |
|                                       |                    |          |  | büS mode only: Invalid producer mapping  | Search may take up to one minute. |

| LED<br>compliant with<br>NAMUR NE 107               | Color code Hex/Dec                                |          | Description<br>according<br>NAMUR NE 107 | Description of device status   | What to do?  |  |
|---|---|----------|--|--|--|--|
|   | Lit   | Flashing |  |  |  |  |
| Red   | 5/5   | 25/37    | Failure                                  | AUTOTUNE defective and aborted.  | Restart AUTOTUNE.  |  |
|   |   |          |  | Sensor defect.   | Maintenance is needed – Contact the manufacturer.        |  |
|   |   |          |  | Internal memory defect.  | Maintenance is needed – Contact the manufacturer.        |  |
|   |   |          |  | Device defect.   | Maintenance is needed – Contact the manufacturer.        |  |
|   |   |          |  | Supply voltage out of specified error limits, potential destruction of the device. | Operate the device within the specifications.            |  |
|   |   |          |  | Bus error (e.g. short Circuit).  | Check the wiring.  |  |
|   |   |          |  | büS mode only: Device cannot find other büS participants.                          | Check the wiring. Operate device with other büS devices. |  |
|   |   |          |  | büS mode only: Device cannot find the allocated process value.                     | Review the allocation of the process value.              |  |
| Allocated büS participant doesn't send cyclic data. | Review the assigned büS participant for a defect. |          |  |  |  |  |

Tab. 3: LED display of the device status and measures – software version A.08 and higher

[www.burkert.com](http://www.burkert.com)