CP1 USA - C01/D6 subject to change

ACCESSORIES OXYBABY®





OXYBABY® Can Piercer

The OXYBABY® Can Piercer is essential for head space analysis of bottles and cans.

Safe interlocking and easy handling guarantees optimal quality controls also for bottles and cans with metal or plastic caps.

The Can Piercer can be adjusted up to 15 inches maximum bottles - or cans height. The integrated needle protection and robust needles prevents needle breakage.

Material: steel

Weight: 16.6 lb (without OXYBABY®)

Dimensions (HxWxD): 23 x 6.1 x 9.3 inches (packed, without

OXYBABY®)

Suitable for OXYBABY® M+ and OXYBABY® 6.0.





OXYBABY® Aquacheck

OXYBABY® Aquacheck is ideal for mini packages lower 2 ml sample gas volume.

The gas volume from two or more packages is collected in the water and analysable by the OXYBABY®.

Material: stainless steel

The OXYBABY® Aquacheck is available with and without water container.

Suitable for OXYBABY® M+ and OXYBABY® 6.0.

Other models, options and accessories available upon request.

ACCESSORIES OXYBABY®



for bottles, cans and mini packaging

Can Piercer: Application in practice

Part No.	Needle length in inches	Hight of bottles, cans in inches	Bottle holder	Overpressure	Pressure regulator w. ball valve and gauge 0.1 - 0.7 bar	Calibration module + flow regulator *	Gauge 0 - 6 bar	Conversion possible	Application	Device
590000156	0.22	106.3		x <14.5 psi(g)				x	beverage cans (without gas / without overpressure), eg. juice	OXYBABY®
590000165	0.33	106.3	x	x >14.5 psi(g)				x	bottles, bevarage cans (with gas / with overpressure), eg. Cola, mineral water	OXYBABY®
590000166	0.33	153.6	x	x >14.5 psi(g)				x	bottles, beverage cans (with gas / with overpressure), eg. Cola, mineral water	OXYBABY®
590000325	0.73	153.6	x	x >14.5 psi(g)				х	bottles, beverage cans (with gas / with overpressure), eg. Cola, mineral water	OXYBABY®
590000239	0.22	106.3		x >14.5 psi(g)	х	х		x	bottles, beverage cans (with gas / with very high over- pressure, sparkling)	OXYBABY® without pump
590000341	0.22	153.6	x	0 - 58 psi			х	х	bottles, beverage cans	no OXYBABY® connection, only pressure measurement

^{*}to prevent the OXYBABY® from damage by too high overpressure, too high flow rate, the calibration module has to be connected between calibration gas / zero gas and OXYBABY®.

Attention:

The correct model of the required Can-Piercer type is dependent on

- the kind of liquid to be analysed,
- the available overpressure in the bottles / cans,
- the volume of the available headspace of the bottles / cans,
- the thickness of the caps / can walls

Our recommendations:

Case	Application	Example	Recommendation
1	for beverages containing gas	cola, mineral water, lemonades, beer, etc.	590000165, 590000166 or 590000325
2	for beverages, free of gas	juices, wine, water mixtures, etc.	590000156
3	EXTREME CASE: for beverages containing gas	with very high overpressure, small volume in the head space of the cans / bottles and / or very strongly sparkling	590000239
4	for sole pressure measurement	from a can or bottle	590000341

Retrofit components and spare parts:

956721800
802128600
956864800
956722000
956674900
956883600
956721700
800707500
800420800

To obtain clear results we adjust a pressure of 7.25 psi and a flow rate of approx. 100 ml/min.